

hergom

E30M Rear Additional Heat Shield For tested Rear clearance of 200mm

The rear clearance of 200mm requires the Firebox headshield as well as the flue shield - a solid 8" flue shield and a deflector included between the 6" active and the 8" flue shield, for the first 900mm of flue.

Otherwise the heater requires a heat resistant non-combustible rear wall.

Included:

- 1 x heatshield
- 1 x support bracket
- 1 x M6 bolt with nut.



Remove the centre bolt from the underside of the E30M base – one of the bolts holding up the base heatshield. Insert the brackets' right angle hook into the slot in the back casting on the rear of the heater, and use the open slotted hole to fix to the underside of the heater with the bolt that had just been removed from the base.

Fix the heatshield to the bracket – the tabs at the top of the heatshield are inserted into the heaters top cast panel and then the bottom of the heatshield is fixed to the bracket.

